

Nachfolgend einsetzbar für folgende Hersteller und Modelle.

Auf Geräte-Nr. achten, E-Nr. , Muster vergleichen.

passend zu AEG (Electrolux-Konzern) Waschgeräte

Geräte- Modellbezeichnung	E-, Produktions-Nr.	F- , FD-, Serien-Nr.
LAVAMAT70500W	91400122100	19970101
LAVAMAT70509W	91400123300	19970101
LAVAMAT70520W	91400139800	19990101
	91400142500	19990101
	91400133900	19980101
LAVAMAT70521W	91400144700	19990802
LAVAMAT70529W	91400134000	19980101
	91400139900	19990101
LAVAMAT70700WB	91400114400	19970101
LAVAMAT70720W	91400133800	19980101
	91400140000	19990101
LAVAMAT71709	Lavamat71709	AEG
LAVAMAT71709W	91400104200	19970101
LAVAMAT71729	Lavamat71729	AEG
LAVAMAT71729W	91400132400	19980101
	91400139700	19990101
LAVAMAT72100W	91400146200	20000303
LAVAMAT72420W	91400146700	20010102
LAVAMAT72520W	91400140600	19990101
	91400142600	19990101
	91400143200	19991115
	91400145900	19991216
LAVAMAT72527W	91400142200	19990101
LAVAMAT72600	91400112800	19970905G
LAVAMAT72600UPDATE	91400115300	19970101
	91400116000	19970101
	91400116200	19970101
	91400102600	19970101
	91400107300	19970101
	91400114600	19970101
LAVAMAT72600WCZ	91400120700	19970101
LAVAMAT72600WGB	91400112800	19970101
LAVAMAT72600WS	91400115000	19970101
LAVAMAT72605UPDATE	91400107500	19970101
LAVAMAT72610W	91400139600	19990101
	91400132800	19980101
	91400105200	19970101
LAVAMAT72620	91400133600	19980501F
LAVAMAT72620W	91400133700	19980101
	91400132300	19980101
	91400133000	19980101
	91400133100	19980101
	91400133300	19980101
	91400133400	19980101
	91400137500	19980101
	91400133500	19980101
	91400133600	19980101
LAVAMAT72625W	91400137300	19980101
LAVAMAT72627W	91400132900	19980101
LAVAMAT72628W	91400143400	19990101
LAVAMAT72666W	91400601400	19991217
LAVAMAT7270010	91400103800	19970101
	91400111700	19970501P
LAVAMAT72700CH	91400115200	19970101
LAVAMAT72700D	91400103800	19970801
LAVAMAT72700W	91400106100	19970101

	91400103700	19960101
LAVAMAT72700WI	91400111700	19970101
LAVAMAT72720W	91400132500	19980101
	91400132700	19980101
	91400132600	19980101
	91400139500	19990101
	91400132100	19980101
LAVAMAT72760W	91400601100	19990101
	91400600100	19970101
	91400601000	19980101
LAVAMAT73600WDK	91400114500	19970101
LAVAMAT73600WUPDATE	91400107200	19970101
LAVAMAT73603UPDATE	91400107600	19970101
LAVAMAT73620	Lavamat73620	AEG
LAVAMAT73620W	91400136700	19980101
	91400135900	19980101
	91400136800	19980101
	91400131900	19980101
LAVAMAT73623W	91400135600	19980101
LAVAMAT73706W	91400104100	19970101
LAVAMAT73708W	91400108900	19970101
LAVAMAT73709	Lavamat73709	AEG
LAVAMAT73709W	91400103900	19960101
LAVAMAT73728W	91400131600	19980101
	91400141900	19990101
LAVAMAT73729	Lavamat73729	AEG
LAVAMAT73729W	91400139400	19990101
	91400131500	19980101
LAVAMAT74100W	91400146300	20000306
LAVAMAT74320W	91400146100	20000303
LAVAMAT74500UPDATE	91400119500	19970101
LAVAMAT74500WN	91400115900	19970101
LAVAMAT74500WS	91400114900	19970101
LAVAMAT74520W	91400131300	19980101
	91400140500	19990101
	91400145800	19991216
LAVAMAT74600	91400112700	19970905G
LAVAMAT74600UPDATE	91400107100	19970101
LAVAMAT74600W	91400114800	19970101
	91400121100	19980101
	91400121200	19980101
	91400123600	19980101
LAVAMAT74600WF	91400116100	19970101
LAVAMAT74600WGB	91400112700	19970101
LAVAMAT74600WN	91400115800	19970101
LAVAMAT74604UPDATE	91400107700	19970101
LAVAMAT74620	91400130700	19980501F
LAVAMAT74620W	91400130900	19980101
	91400131100	19980101
	91400130700	19980101
	91400135800	19980101
	91400143500	19990101
	91400130400	19980101
	91400130600	19980101
	91400131000	19980101
	91400130500	19980101
LAVAMAT74624W	91400135400	19980101
LAVAMAT74700	91400111600	19970501P
	91400119000	19970901P
LAVAMAT74700AP	91400103500	19960101
LAVAMAT74700CB	91400103400	19960101
LAVAMAT74700CH	91400115100	19940101
LAVAMAT74700E	91400119000	19970101
LAVAMAT74700TT	91400103300	19960101

LAVAMAT74700UPDATE	91400102500	19960101
LAVAMAT74700W	91400106000	19970101
LAVAMAT74700WI	91400111600	19970101
LAVAMAT74720W	91400129700	19980101
	91400129800	19980101
	91400129900	19980101
	91400136300	19980101
	91400143100	19990101
	91400139300	19980101
	91400130100	19980101
	91400130200	19980101
LAVAMAT74724W	91400138400	19980101
LAVAMAT74728W	91400143300	19990101
LAVAMAT75520W	91400138600	19990101
LAVAMAT75600	Lavamat75600	AEG
LAVAMAT75600W	91400114700	19970101
LAVAMAT75600WDK	91400115400	19970101
LAVAMAT75600WN	91400115700	19970101
LAVAMAT75620	Lavamat75620	AEG
LAVAMAT75620W	91400129600	19980101
	91400129400	19980101
	91400129500	19980101
LAVAMAT75700	Lavamat75700	AEG
LAVAMAT75700UPDATE	91400107000	19970101
LAVAMAT75703UPDATE	91400107900	19970101
LAVAMAT75720W	91400135700	19980101
LAVAMAT75723W	91400135500	19980101
LAVAMAT75725	Lavamat75725	AEG
LAVAMAT75725W	91400129200	19980101
LAVAMATBELLASW	91400136000	19980101
LAVAMATBELLAW	91400107800	19970101
LAVAMATDIAMANTEW	91400140100	19980101
LAVAMATDIAMANTLW	91400140200	19990101
LAVAMATDIAMANTSW	91400140300	19980101
LAVAMATDIPLOMATSW	91400136400	19980101
LAVAMATDIPLOMATW	91400115500	19970101
LAVAMATEXCLUSIVSW	91400136500	19980101
LAVAMATFUTUREW	91400136900	19980101
LAVAMATPRINCESSSW	91400136100	19980101
LAVAMATPRINCESSW	91400107400	19970101
LAVAMATUPDATEW	91400115600	19970101

passend zu Electrolux ElectroluxWascator (Electrolux-Konzern) Waschgeräte

Geräte- Modellbezeichnung	E-, Produktions-Nr.	F-, FD-, Serien-Nr.
EW1380FW	91400142000	19990101
EW1585FW	91400141100	19990101

passend zu Matura (Quelle-Gruppe) Waschgeräte

Geräte- Modellbezeichnung	E-, Produktions-Nr.	F-, FD-, Serien-Nr.
ÖKO8511	Öko8511	Matura
ÖKO8511W	91400109700	19970101
ÖKO8513	Öko8513	Matura
ÖKO8513W	91400109600	19970101
ÖKO8515	Öko8515	Matura
ÖKO8515W	91400109500	19970101
ÖKO8611W	91400135100	19980101
	91400144300	19990802
ÖKO8613W	91400135200	19980101
	91400144200	19990802
ÖKO8615W	91400135300	19980101
	91400144100	19990802

passend zu NECKERMANN Lloyds Waschgeräte / Lavamat72420

Geräte- Modellbezeichnung	E-, Produktions-Nr.	F-, FD-, Serien-Nr.
074575000 LAV72420 914001467 LAVAMAT72420W	074575000 LAV72420 914001467 LAVAMAT72420W	(Quelle NEU) Neckermann
148115000 LAVAMAT70520 914001398 LAVAMAT70520 LAVAMAT70520	148115000 LAVAMAT70520 914001398 LAVAMAT70520 LAVAMAT70520	(Quelle NEU) Neckermann
148131000 LAVAMAT72720 914001395 LAVAMAT72720 LAVAMAT72720UPDATE	148131000 LAVAMAT72720 914001395 LAVAMAT72720 LAVAMAT72720UPDATE	(Quelle NEU) Neckermann
148172000 LAV72720W 914001395 LAV72720W	148172000 LAV72720W 914001395 LAV72720W	(Quelle NEU) Neckermann
148474000 LAVAMAT72520 914001406	148474000 LAVAMAT72520 914001406	(Quelle NEU) Neckermann
777005000 LAVAMAT74520 914001458 LAVAMAT74520 LAVAMAT74520W	777005000 LAVAMAT74520 914001458 LAVAMAT74520 LAVAMAT74520W	(Quelle NEU) Neckermann

passend zu Quelle (Quelle-Gruppe) Waschgeräte / Waschautomat 6742

Geräte- Modellbezeichnung	E-, Produktions-Nr.	F-, FD-, Serien-Nr.
09925001 6742 914001351914001443 MATURAFUZZY8611W	09925001 6742 914001351914001443	(Quelle NEU) Matura
09925101 6743 914001352914001442 MATURAFUZZY8613W	09925101 6743 914001352914001442	(Quelle NEU) Matura
09925901 6744 MATURAFUZZY8615	09925901 6744 MATURAFUZZY8615	(Quelle NEU) Matura
12949001 MARKE 914001339 AEGLAVAMAT70520	12949001 MARKE 914001339 AEGLAVAMAT70520	(Quelle NEU) AEG
12949201 MARKE 914001321 AEGLAVAMAT72720	12949201 MARKE 914001321 AEGLAVAMAT72720	(Quelle NEU) AEG
12952101 MARKE 914001302 AEGLAVAMAT74720	12952101 MARKE 914001302 AEGLAVAMAT74720	(Quelle NEU) AEG
15209501 6853 941001097 MATURAOEKOTRONIC8511	15209501 6853 941001097 MATURAOEKOTRONIC8511	(Quelle NEU) Matura
15210501 6854 914001096 MATURAOEKOTRONIC8513	15210501 6854 914001096 MATURAOEKOTRONIC8513	(Quelle NEU) Matura
15211501 6855 914001095 MATURAOEKOTRONIC8515	15211501 6855 914001095 MATURAOEKOTRONIC8515	(Quelle NEU) Matura
15290501 MARKE 0 AEGLAVAMAT72700	15290501 MARKE 0 AEGLAVAMAT72700	(Quelle NEU) AEG
15291501 MARKE 914001025 AEGLAVAMAT74700	15291501 MARKE 914001025 AEGLAVAMAT74700	(Quelle NEU) AEG
19362601 LAVAMAT74100W 914001463 LAVAMAT74100W WVALAVAMAT74100W	19362601 LAVAMAT74100W 914001463 LAVAMAT74100W WVALAVAMAT74100W	(Quelle NEU) Quelle